





 Phâro™

 salon sugaring system



roll-on cartridge heater

for use with Phâro sugaring gel

Magnetic Base Unit for Increased Stability

Fully Adjustable Heat Settings

Thermostatically Controlled

Docking Facility for Multi-Unit versatility

Rapid Heating

instructions for using the Phâro roll on system

- Screw on a roller head to the cartridge and place it in heater with the roller face forward.
- To heat a cartridge quickly, turn the temperature control knob to 4 for 4/5 mins .
- To test the consistency pull out the cartridge from the heater and turn it over to check that the gel has reached a flowing consistency. If it has, then with the cartridge still held upside down, gently squeeze the cartridge till the gel just oozes through the roller head.
- Put the cartridge back into the heater unit and turn the temperature control knob down to between 2 and 3.
- Lift the hand unit out of the base, turn it upside down and roll out a couple of times on a waxing strip to get the gel flowing through evenly.
- Between applications return the hand unit to the base to allow re heating.
- The cartridge is now ready to use. Roll on the gel in the direction of hair growth (e.g. downwards on the legs).





 Phâro™

 salon sugaring system



sugaring gel pot heater

for use with Phâro sugaring gel

Sealed Heat Chamber

Fully Adjustable Heat Settings

Power Indicator Light

Rapid Heating

instructions for using the Phâro pot warmer system

- Remove the cap and inner seal from the gel pot and stand the pot in the chamber of the heater.
- To heat a pot quickly, turn the temperature control on full. (15 to 20 minutes).
- As the gel approaches a flowable state, put a wooden spatula into the pot and stir the gel to achieve a uniform consistency.
- Set temperature control to between 3 and 4 to maintain gel temperature.

instructions for microwave heating a pot

- Note: Take care **never** to overheat the sugaring gel.
- Remove the cap and inner seal from 700g gel pot and place pot in microwave.
- Heat for typically **one minute for a full pot** (scale down accordingly) until the gel has a consistency similar to pourable liquid honey. As the gel approaches a flowable state, Stir with a wooden spatula to achieve a uniform consistency.
- Take the pot out and put it into the pot warmer (set at about 4) to maintain the temperature. **TEST THE TEMPERATURE BEFORE APPLYING.**